
VLSI Design Automation

Outline


- Technology trends
- VLSI Design flow (an overview)

IC Products

- Processors
 - CPU, DSP, Controllers
- Memory chips
 - RAM, ROM, EEPROM
- Analog
 - Mobile communication, audio/video processing
- Programmable
 - PLA, FPGA
- Embedded systems
 - Used in cars, factories
 - Network cards
- System-on-chip (SoC)



Integrated Circuit Revolution



1972: Intel 4004 Microprocessor


Clock speed: 108 KHz

Transistors: 2,300

I/O pins: 16

Technology: 10 μ m

Integrated Circuit Revolution




2000: Intel Pentium 4 Processor

Clock speed: 1.5 GHz

Transistors: 42 million


Technology: 0.18 μ m CMOS

Integrated Circuit Revolution



2006: Intel Core 2 Duo
Clock speed: 3.73 GHz
Transistors: 1 billion
Technology: 65nm CMOS


Integrated Circuit Revolution



2005: Sun UltraSparc T1
8 cores, 4 threads per core
Clock speed: 1.2 GHz
Transistors: 300 million
Technology: 90nm CMOS

Moore's Law


- *Gordon Moore* predicted in 1965 that the number of transistors that can be integrated on a die would **double every 18 months**.




Semiconductor Growth



Processor Power (Watts)



Intel Microprocessor Performance



Device Complexity

- Exponential increase in device complexity
 - Increasing with Moore's law (or faster)!
- Require exponential increases in design productivity

We have exponentially more transistors!

Heterogeneity on Chip


- Greater diversity of on-chip elements
 - Processors
 - Software
 - Memory
 - Analog

More transistors doing different things!

Stronger Market Pressures

- Time-to-market
 - Decreasing design window
 - Less tolerance for design revisions

How Are We Doing?




Role of EDA: close the productivity gap


Evolution of Design Methodology

- We are now entering the era of *block-based design*

ASIC/ASSP
Design




Yesterday
Bus Standards,
Predictable, Preverified




System-Board
Integration

IP/Block
Authoring




Today
VSI Compatible Standards,
Predictable, Preverified



System-Chip
Integration

Evolution of SoC Platforms



2 Cores: Philips' Nexperia PNX8850 SoC platform for High-end digital video (2001)

What's Happening in SoCs?

■ Technology: no slow-down in sight!

Faster and smaller transistors: 90 → 65 → 45 → 32 nm

→ ... but slower wires, lower voltage, more noise!

✓ 80% or more of the delay of critical paths will be due to interconnects

■ Design complexity: from 2 to 10 to 100 cores!

→ Design reuse is essential

→ ...but differentiation/innovation is key for winning on the market!

■ Performance and power:


→ Performance requirements keep going up

→ ...but power budgets don't!

Communication Architectures


■ Shared bus

- Low area
- Poor scalability
- High energy consumption




■ Network-on-Chip

- Scalability and modularity
- Low energy consumption
- Increase of design complexity





Intel's Teraflops




- 100 Million transistors
- 80 cores, 160 FP engines
- Teraflops perf. @ 62 Watts
- On-die mesh network
- Power aware design

IC Design Steps




IC Design Steps




Circuit Models

- A *model of a circuit* is an *abstraction*
 - A representation that shows relevant features without associated details



Model Classification



Levels of Abstraction

■ Architectural

- A circuit performs a set of operation, such as *data computation* or *transfer*
 - ✓ HDL models, Flow diagrams, ...


■ Logic

- A circuit evaluate a set of *logic functions*
 - ✓ FSMs, Schematics, ...

■ Geometrical

- A circuit is a set of *geometrical entities*
 - ✓ Floor plans, layouts, ...

Levels of Abstraction



Views of a Model

■ Behavioral

→ Describe the function of a circuit *regardless* of its implementation


■ Structural

→ Describe a model as an *interconnection* of components

■ Physical


→ Relate to the *physical object* (e.g., transistors) of a design

The Y-chart



Gajski and Kuhn's Y-chart
(Silicon Compilers, Addison-Wesley, 1987)

The Y-chart



Synthesis

